



## ***Extra Large Button Talking Clock Instructions***

### **Getting started**

#### **Inserting the batteries:**

This clock is powered by three (3) AAA batteries. Turn the clock over so the base is facing upwards and locate the battery cover. Locate the fingertip catch on the long side of the battery cover. Using your fingertip, gently pull the clip and lift the cover away from the body of the clock.

Insert each battery noting the correct polarity, with the negative (flat) end of each battery positioned against the spring. Once both batteries are inserted, re-attach the battery cover ensuring that the two locating lugs sit into the bottom edge of the battery compartment. Close the cover, you will know when it's properly located as you will hear an audible click confirming the cover is correctly fitted.

It is recommended that you replace the batteries annually, even if the clock is still running. Only use AAA (1.5V) alkaline batteries in this clock. Remove the batteries if the clock is not in use for an extended period. Please dispose of used batteries in a responsible manner. For more information please contact your local authority.

### **Using the product**

#### **Setting the spoken time:**

**Please note:** When entering the settings menu and for any reason there is no activity after five seconds, you will hear an audible high-pitched beep. This indicates that the clock has reverted to normal time mode. To re-enter the settings mode, press the mode button and scroll through to the desired settings function and continue.

With the back of the clock facing towards you, locate the **mode button**. Sequential presses of the “**mode button**” will take you through the setting menu. These are announced in the following order:

- 1 press = **set hour**
- 2 presses = **set minute**
- 3 presses = **set year**
- 4 presses = **set month**
- 5 presses = **set day**
- 6 presses = **set alarm hour**
- 7 presses = **set alarm minute**
- 8 presses = **set alarm**

To set the time, press and release the **mode button**, you will hear the command “**set hour**”. Then use the **talk button** to select the correct hour and this will be heard as either “am” or “pm”. When you have selected the correct hour, press the **mode button**. You will hear the command “**set minute**”. Again, use the **talk button** to select the desired minute.

Having selected the correct hour and minute, release all buttons and after five seconds you will hear a high-pitched beep. This confirms that the clock has reverted to normal time mode and has come out of the setting menu mode. To hear and confirm the time you have set, press the **talk button**. This will be announced as “the time is...followed by the time you have set.

To correct or further adjust the time, press the **mode button** until the setting you want to adjust is announced. Then follow the above steps until the correct time is selected.

## Setting the date:

To set the date, press and release the **mode button**, until you hear the command “**set year**”. Use the **talk button** to select the correct year, this will be heard as dates from 14 to 23. When you have selected the correct year, press the **mode button** and you will hear the command “**set month**”. Again, use the **talk button** to select the desired month. With the correct month selected, press the **mode button** and you will hear the command “**set day**”, select the correct day using the **talk button**.

Having selected the correct year, month and day, release all buttons and after five seconds you will hear a high-pitched beep. This confirms that the clock has reverted to normal time mode and has come out of the setting menu mode. To hear and confirm the date you have set, press the **talk button** once to hear the time, press a second

time and you will hear the date announced as “the date is...followed by the date you have set.

To correct or further adjust the date, press the **mode button** until the setting you want to correct or further adjust is announced. Then follow the above steps until the correct date is selected.

## Setting the alarm:

To set the alarm, press and release the **mode button**, until you hear the command “**set alarm hour**”. Use the **talk button** to select the correct hour. When you have selected the correct hour, press the **mode button** and you will hear the command “**set alarm minute**”. Again, use the **talk button** to select the desired time.

Having selected the correct hour and minute, press the **mode button** until you hear the command “**set alarm**”. Press the **talk button** and select either “**alarm OFF**” or “**alarm ON**”. Alarm OFF is followed by a low pitch double beep. Alarm ON is followed by a high pitch double beep. After setting the alarm, release all buttons and after five seconds you will hear a high-pitched beep. This confirms that the clock has reverted to normal time mode and has come out of the setting menu mode.

When the alarm time you have set sounds, the clock will beep indicating the alarm is sounding. To turn the alarm off, press the **talk button**. This de-activates the alarm and then announces the time.

### **Please Note: This Clock has a voice sleep mode function.**

The sleep mode can be used when travelling or when you require the clock to remain silent. The clock will remain silent even if a button is pressed.

**To activate sleep mode:** Press and hold either the talk or set button and **hold for 8 seconds**, you will hear **2 short beeps** to confirm that the clock is in sleep mode.

**To re-activate the voice:** Press and hold either the talk or set button and **hold for 8 seconds**, you will hear **4 short beeps** to confirm that the voice is reactivated.



Owned and Operated by LIBERTY Health Supply, LLC

LIBERTY Health Supply  
28045 N. Ashley Circle Suite 103  
Libertyville, IL 60048